Hamilton Manufacturing Corporation

1026 Hamilton Dr. Holland, OH 43528 • Phone: 419-867-4858/800-837-5561 • Fax: 419-867-4867 • www.hamiltonmfg.com

STA Installation Instructions for a Rear Load Changer

- 1. Unplug the power cord or remove all power from the system at the circuit breaker.
- 2. Remove the existing stacker and validator.
- 3. Remove the validator bracket from the mounting studs located on the front wall of the cabinet. Disconnect the heater pad (if present) and remove it as well.
- 4. Secure the new validator mounting bracket assembly (37-0055B) to the studs on the front wall of the cabinet using four 1/4-20 nuts.
- 5. Secure the adhesive backed foam seal to the inside of the cabinet front around the validator opening.
- 6. Connect the small end of the 9-pin harness adapter to the STA validator and the other end to the system harness.
- 7. Slide the validator into the validator bracket from the rear.
- 8. Connect the stacker harness and hang the stacker from the back of the validator mounting bracket.

General Page 1 of 1 8/31/01