

Hamilton Manufacturing Corporation

1026 Hamilton Dr. Holland, OH 43528 • Phone: 419-867-4858/800-837-5561 • Fax: 419-867-4867 • www.hamiltonmfg.com

INSTALLATION AND REMOVAL INSTRUCTIONS FOR ACW BUTTON

PART # 47-0050 (RED BUTTON)
PART # 47-0084 (BLACK BUTTON)
PART # 47-0049 (CONTACT BLOCK)

INSTALLATION

- A. Engage the OPERATOR (1) into the 22.5mm diameter mounting hole.
- B. Mount the BACK-UP NUT (2) onto the bushing and then tighten against the panel.
- C. Snap the CONTACT BLOCKS (4) onto the SUPPORT (3).
- D. Snap the SUPPORT (3) complete with CONTACT BLOCKS onto the OPERATOR (1).

REMOVAL

- A. Place finger behind D SUPPORT (3) and lift away from cabinet.
- B. Remove BACK-UP NUT (2) on bushing by untightening.
- C. Remove OPERATOR (1) from mounting hole.

NOTE:

If replacing wires, first put the wires back on the CONTACT BLOCK, then use silicone to reattach the wires to the CONTACT BLOCK.

